

## RS 232 cable MPU to PC

MPU – canon 9F	PC – canon 9F
2 - Tx	2 - Rx
3 - Rx	3 - Tx
5 - GND	5 - GND